

All drawings and information are the property of the architect and are not to be used for any other purpose without the written consent of the architect.  
[PRINTING INSTRUCTIONS] The printer is responsible for ensuring that the drawing is printed at the correct scale and that all text is legible. The printer is also responsible for ensuring that the drawing is printed on the correct paper and that all lines are sharp and clear. The printer is also responsible for ensuring that the drawing is printed in black and white and that all colors are accurate. The printer is also responsible for ensuring that the drawing is printed on the correct side of the paper and that all lines are sharp and clear. The printer is also responsible for ensuring that the drawing is printed on the correct scale and that all text is legible.

**KRISS LOWRY & ASSOCIATES**  
CORINTH, KY.

2BED-884-A

711 Lyndon Lane  
Louisville KY, 40222  
362.429.8896  
Fax 362.429.8897

**PHOENIX RISING**  
ARCHITECTURAL DESIGN



Sheet:


**A.4**

Title: ELEVATIONS


Date: MARCH 5, 2004

Rev: \_\_\_\_\_

Rev: \_\_\_\_\_



1 A.4  
LEFT ELEVATION  
SCALE: 1/4" = 1'-0"



2 A.4  
RIGHT ELEVATION  
SCALE: 1/4" = 1'-0"